


On the provided list of device serial numbers, add the location for the Range Extender.

Example

⚠ There are no user-serviceable parts inside the device. Unauthorized dismantling will void the warranty. For warranty information, see www.autani.com/legal.

Plug in the Range Extender.



- Near electrical equipment such as computer servers or electrical breaker panels
- Where the signal travels through concrete walls or floor

Join the Range Extender to the autaniNet network.

- If the Range Extender is being installed with an Autani Manager and other devices, see the complete documentation package for the Autani Manager.
- If an Autani Manager and other devices were installed before:
 1. Click **Settings** on the left navigation bar of the Autani software.
 2. Click the **Device Setup** tab.
 3. Click the **Add Device(s)** button.
 4. Select the row of the Range Extender being installed.
 5. Click **Next**.
 6. Review the Range Extender information.
 7. Click **Next**.
 8. Click **Finish**.

LED1 color changes indicate the stages of the device joining the network.

