Model #
1000152-09-26



1

On the provided list of device serial numbers, add the location for the Range Extender.

There are no user-serviceable parts inside the Device. Unauthorized dismantling will void the warranty. For warranty information, see www.autani.com/legal.

2

Connect the Range Extender to 12-24V AC or DC.

Color	Description
Red	12-24V
Black	Common

NOTE: Range is 1000 feet "line-of-sight" distance for transmission/reception. Range is reduced when the signal travels through walls, floors, ceilings, or other objects. Avoid placing the Range Extender:

- ❑ Near electrical equipment such as computer servers or electrical breaker panels
- ❑ Where the signal travels through concrete walls or floor

3

Join the Range Extender to the autaniNet network.

- ❑ If the Range Extender is being installed with an Autani Manager and other devices, see the complete documentation package for the Autani Manger.
- ❑ If an Autani Manager and other devices were installed before:

1. Click **Settings** on the left navigation bar of the Autani software.
2. Click the **Device Setup** tab.
3. Click the **Add Device(s)** button.
4. Select the row of the Range Extender being installed.
5. Click **Next.**
6. Review the Range Extender information.
7. Click **Next.**
8. Click **Finish.**

4

LED1 color changes indicate the stages of the device joining the network.



LED Color		Device Status Description
	Red	When device is powered, it automatically searches for network.
	Amber	Device has found an Autaninet network and is waiting for permission to join.
	Green	Device has been added to the network and is Actively communicating.

Copyright Autani, LLC 2020. All rights reserved. For warranty and other legal information, go to www.autani.com/legal.